

PROMO

Spiral kneader 22 Liters, timer, on wheels

FD22/M1-S

Descriptions

| | |
|--------------------------|---------------------|
| mm (W x D x H) | 390 x 670 x 730 |
| kW | 0.75 |
| Voltage | 230/1N 50HZ |
| Hp | 1 |
| gross Weight (Kg) | 70 kg |
| Volume (m ³) | 0.24 m ³ |

Page Promo : 61-Pr23-24

Product details

- 1-speed model.
- Timer as standard.
- Diameter of the bowl 350 mm (22 liters) = +/-18 kg of dough.

- Frame made of steel with oven painting.
- Rotating bowl (not removable) in stainless steel AISI 304.
- Spiral in high hardness steel, dividing ploughshare in stainless steel AISI 304.
- Stainless steel grid equipped with a safety micro switch.
- Transmission by gear motor in oil bath, reliable, efficient and silent!
- Suspended motor, better ventilation, easy maintenance.
- Control panel with IP21 protection.
- Standard delivered with wheels, 2 of which are equipped with brakes.

- The device is built in compliance with the CE standards in force.

The +

ADVANTAGE:

Spiral Line EVO brand new, more robust, more efficient kneaders, available in 11 different versions;
- ...- T2V = 2 speeds; AL/T2V = Tilting head and removable bowl. Delivered as standard on wheels including 2 equipped with brakes, An unbeatable price/quality ratio!