

PROMO**? BEST CHOICE**

Whole ice cube maker 155 kg, with storage - AIR

ICE155A-R2

Descriptions

mm (W x D x H)	840 x 740 x 1075(+110)
kW	1.4
Voltage	230/1N 50HZ
gross Weight (Kg)	138 kg
Volume (m ³)	0.84 m ³

Page Catalog : **694-Ed8**Page Promo : **3-Pr24-25**

Product details

- Produces 155 kg per 24 hours, storage in plastic, capacity 65 kg.
- 18 g ice cubes
- Refrigerant gas R290
- 4 lower regulation cylinders
- Electronic timer with automatic washing system "AWS".
- Air condenser.
- "Spray" system with brass nozzles, (designed to prevent the magnetization of limestone).
- Tropicalized hermetic unit ambient temperature + 43 ° C
- Manufactured in stainless steel AISI 304, adjustable feet.
- The equipment is manufactured following the (CE) standards in force.

The +

ADVANTAGE:

Messing nozzles, designed to avoid lime magnetization. Water connection during the cycle in closed circuit. Ice cubes, compact and crystal clear. Their shapes meet all the demands of the sector.

Electronic timer with automatic washing system "AWS" (available only in stainless steel versions from 22Kg to 70Kg) allowing the cleaning/descaling without using the cooling cycle.