



Ventilated refrigerator GN 2/1, 600 liters. stainless steel

PV600X-R6

Descriptions

mm (W x D x H)	780 x 740 x 1925
T°	-1°+6°
kW	0.4
Voltage	230/1N 50HZ
gross Weight (Kg)	98 kg
Volume (m ³)	1.1 m ³

Page Catalog : 528-Ed8

Product details

- Temperature -1° +6°
- Refrigerant R600a
- Ventilated Evaporator, Roll bond type
- Automatic defrost, auto-evaporation of condenser water
- Delivered with 3 grids (very robust) GN 2/1 (651x510 mm), adjustable as well as the bottom grid (651x380 mm).

- Exterior manufactured in stainless steel 430, white interior, lacquered steel sheet)
- Door (reversible), with magnetic seal closure (by pressure), easy changing without tools, ergonomic handle.
- Key lock door, standard
- Electronic regulation, digital display
- Polyurethane insulation (60 mm), without CFC's
- Cooling unit with climate category 4 (placed behind)
- 4 adjustable feet, stainless steel.
- The equipment is manufactured following the (CE) standards in force.

The +

- "Environmentally responsible" refrigerators (Made in Europe), eco-friendly refrigerant R600A or R290.
- Low energy use, more powerful components, electronic regulator.
- Possibility to place them "Side by Side"
- On request PVC storage boxes (Ref: CBP1/1).